

Instruction for electronic motor remote reprogram



1. Remove 4 plastic screws on the control box cover of the motor.
2. On the electronic card, locate the button next to the flashing red light.
3. Press this button (red light will stop flashing)
4. Press immediately the « UP » button on the remote (red light will restart flashing)
5. Release button on remote and press again (motor will start)
6. Repeat the same operation for other remote controls.
7. Reattach the control box cover.

Use of padlock



Lock :

1. Press once on the « UP » button of remote to activate motor.
2. Press the « LOCK » button during 8 seconds and release.
3. The lock system is activated, if not, repeat the operation.

Unlock :

1. Press once on the « UP » button of remote to activate motor
2. Press the « LOCK » button during 8 seconds and release.
3. The lock system is disabled, if not, repeat the operation.